

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курган (3522)50-90-47
 Курск (4712)77-13-04
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Новосибирск (383)227-86-73
 Ноябрьск (3496)41-32-12
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Пермь (342)205-81-47
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саранск (8342)22-96-24
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

yne@nt-rt.ru || <https://yuken.nt-rt.ru>

005 Series Modular Valves

Type of Modular Valve


Class	Name and Model Numbers	Graphic Symbols	Page
	Solenoid Operated Directional Valve DSG-005- * * * - * -40		★
Pressure Control Valves	Relief Valves (for "P-Line") MBP-005- * -20		F-8
	Reducing Valves (for "P-Line") MRP-005- * -20		F-8
Flow Control Valves	Throttle and Check Valves (for "A-Line", Meter-out) MSA-005-X-20		F-8
	Throttle and Check Valves (for "A-Line", Meter-in) MSA-005-Y-20		
	Throttle and Check Valves (for "B-Line", Meter-out) MSB-005-X-20		
	Throttle and Check Valves (for "B-Line", Meter-in) MSB-005-Y-20		
	Throttle and Check Valves (for "A&B-Lines", Meter-out) MSW-005-X-20		
	Throttle and Check Valves (for "A&B-Lines", Meter-in) MSW-005-Y-20		
Directional Control Valves	Check Valves (for "P-Line") MCP-005-0-20		F-8
	Pilot Operated Check Valves (for "A-Line") MPA-005-2-20		F-8
	Pilot Operated Check Valves (for "B-Line") MPB-005-2-20		
	Pilot Operated Check Valves (for "A&B-Lines") MPW-005-2-20		
Modular Plates and Mounting Bolts	End Plates (Blocking Plates) MDC-005-A-20		F-8
	Base Plates MMC-005- * -20		F-8
	Bolts Kits MBK-005- * -20		F-8

★Please refer to the catalog page of "E: Directional Control Valves".

Relief Modular Valves

Specifications


Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MBP-005-* -20	25	15



Reducing Modular Valves

Specifications


Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MRP-005-* -20	25	15



Throttle and Check Modular Valves

Specifications


Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MS*-005-* -20	25	15



Check Modular Valves

Specifications


Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MCP-005-0-20	25	15



Pilot Operated Check Modular Valves

Specifications

Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MP*-005-2-20	25	15



End Plates

Blocking plates are used for auxiliary mounting surface or for closing unnecessary circuits.




Specifications

Model Numbers	Max. Operating Pressure MPa
MDC-005-A-20	25

Base Plates For Modular Valves

Specifications

Model Numbers	Max. Operating Pressure MPa
MMC-005-* -20	25



Mounting Bolt Kits For Modular Valves

To mount the valves, four M4 bolts are used. The combination of valves varies with circuits. So, we have several mounting bolt kits suitable for different valve combinations.

















Model Numbers

MBK-005-* -10

007 Series Modular Valves

■ Type of Modular Valve

Class	Name and Model Numbers	Graphic Symbols	Page
	Solenoid Operated Directional Valve DSG-007-***-*-10		★
Pressure Control Valves	Reducing Valves (for "P-Line") MRP-007-*-10		F-10
	Throttle and Check Valves (for "A-Line", Meter-out) MSA-007-X-10		F-10
Throttle and Check Valves (for "A-Line", Meter-in) MSA-007-Y-10			
Flow Control Valves	Throttle and Check Valves (for "B-Line", Meter-out) MSB-007-X-10		
	Throttle and Check Valves (for "B-Line", Meter-in) MSB-007-Y-10		
	Throttle and Check Valves (for "A&B-Lines", Meter-out) MSW-007-X-10		
	Throttle and Check Valves (for "A&B-Lines", Meter-in) MSW-007-Y-10		
Directional Control Valves	Pilot Operated Check Valves (for "A-Line") MPA-007-2-10		F-10
	Pilot Operated Check Valves (for "B-Line") MPB-007-2-10		
	Pilot Operated Check Valves (for "A&B-Lines") MPW-007-2-10		
Modular Plates and Mounting Bolts	End Plates (Blocking Plates) MDC-007-A-10		F-10
	Base Plates MMC-007-*-10		F-10
	Bolts Kits MBK-007-*-10		F-10


★Please refer to the catalog page of "E: Directional Control Valves".

●Further information about 007 series modular valves, please consult your Yuken representative.

Reducing Modular Valves

Specifications


Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MRP-007- *-10	25	15



Throttle and Check Modular Valves

Specifications

Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MS *-007- *-10	25	15



Pilot Operated Check Modular Valves

Specifications

Model Numbers	Max. Operating Pressure MPa	Max. Flow L/min
MP *-007-2-10	25	15



End Plates

Blocking plates are used for auxiliary mounting surface or for closing unnecessary circuits.

Specifications


Model Numbers	Max. Operating Pressure MPa
MDC-007-A-10	25



Base Plates For Modular Valves

Specifications

Model Numbers	Max. Operating Pressure MPa
MMC-007- *-10	25



Mounting Bolt Kits For Modular Valves

To mount the valves, four M4 bolts are used. The combination of valves varies with circuits. So, we have several mounting bolt kits suitable for different valve combinations.

Model Numbers
MBK-007- *-10



По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курган (3522)50-90-47
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Ростов на Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саранск (8342)22-96-24
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93